

"Your Trusted Leader In Insect Control"

HOW TO CLEAN NOZZLE TIPS

- 1. First you will need 2 crescent wrenches to break loose the tip. You do this by putting one wrench on the body of the nozzle and one wrench tip of the nozzle and twist to break the tip loose.
- 2. Once the tip is removed then use your fingers to loosen the brass filter on the backside of the tip. If the filter is stuck on then use a pair of pliers gently to remove the filter.
- 3. Now that the filter is removed, there is a slot on the backside of the tip that is for a flat head screwdriver. Remove this piece carefully because it is spring loaded. Once it is unscrewed the remaining part will fall out.
- 4. Place all but the rubber O ring in a can of distilled white vinegar and let sit for 24 hr. then rinse and scrub clean with an old tooth brush.
- 5. Reassemble the tips and they should work like new. If they don't, you will need to replace them.