

Protecting Structures from Moisture and Fungi after Flooding

By DoMyOwn staff

OVERVIEW

The Complete Guide to Protecting Structures After Flooding

Learn How to Protect Your Home After a Flood

There is a genuine need to help clean out flooded homes, remove the sheetrock and dry the home.

Understand that habitable, flooded homes have been wet and very warm for several weeks. The flood waters likely deposited bacteria in the structures, and the warm, wet conditions resulted in the widespread growth of mold and decay fungi. Once the home is dry you can reinstall a termite barrier and the home is ready for repair.

Proper protective equipment including lightweight moisture-resistant coveralls, chemical resistant gloves and boots, respirator and eye protection should be worn during cleaning operations. **For safety, make sure that the electricity and gas have been turned off prior to all cleaning activities.**



GET 10% OFF: Use code **RENEW25** at checkout

Through 10/31/25, DoMyOwn is offering those in flood-affected areas a 10% discount on select products used in protecting structures from moisture and fungi after flooding.* Offer valid only for residents of FL, TX, NM, NY, NJ, NC & OH. [Shop Now >](#)

STEP 1 Safety First

Wear appropriate protective gear and make sure the electricity, gas and HVAC are off.

Products needed for Step 1



DoMyOwn

Tyvek Disposable Coveralls with Hood and Booties

\$17.30

★★★★☆ (13)

STEP 2 Clean Out the Affected Area



Remove all flooring, furniture, appliances, clothes and other items wetted by floodwaters. Try your best to remove all mud and debris as well.

STEP 3 Tear Out Affected Wall Coverings



Remove interior wall coverings and insulation in the wall cavities. Cut out sheetrock 2 feet above the highest water line to allow for proper drying.

STEP 4 Clean and Disinfect
Clean thoroughly and disinfect with an appropriate EPA registered disinfectant, sanitizer and virucide.



Wash the wall cavities and wall framing with an aqueous detergent solution using low to moderate pressure. Several people are using bleach solutions for such operations, but this is not recommended except when small areas are to be cleaned. While bleach is germicidal, its corrosivity can compromise electrical connections and more. In addition, building materials will absorb large amounts of bleach, causing the gradual release of chlorine gas into the living space for an extended period of time.

Nisus DSV is an approved disinfectant, sanitizer and virucide for this step.

Products needed for Step 4



**Nisus DSV - Disinfectant Sanitizer
Virucide**

\$45.08

★★★★★ (17)

STEP 5 Dry Out the Structure

Open doors & windows to begin circulating fresh air. Place fans throughout the structure to increase the rate of drying and use dehumidifiers if available.

Use a moisture meter to determine when wood is 19% or less moisture content. Failure to make sure the moisture content is at or below this level will result in additional mold growth within the wall cavities. **When the framing is dry, the electrical connections and plumbing within the walls should be checked by licensed professionals.**

Products needed for Step 5



DoMyOwn

**Santa Fe Compact70
Dehumidifier**

\$1,415.00

★★★★☆ (3)

STEP 6 Treat All Wood Framing



Photo: Nisus Corporation, all rights reserved

Kill existing mold and stop new mold from growing by spray-treating the framing and wall cavities with a non-volatile antimicrobial that is registered by the EPA for that use. We recommend using [Bora-Care with Mold-Care](#) in a 5:1 solution. This product contains both borate and a mold control agent.

Flooding can remove existing termite control products from wood and create an environment that can attract termites to wood. Apply termite protection to wood studs with a 2-foot wide band treatment using Bora-Care in a 1:1 solution. Once dry, the home is ready for repair.

Products needed for Step 6



**Bora-Care with
Mold-Care**

\$133.80

★★★★☆ (71)